

Features

- External sound sources can be controlled via Bluetooth MIDI
- Equipped with reverb effect
- 20 built-in sound tones

- Play along with music from your smartphone using Bluetooth Audio
- Built-in speaker
- Headphone/ line output

- Equipped with 24 keys, equivalent to a saxophone
- 6 types of fingerings can be selected
- Powered by USB or 4 AA batteries
- ±12 transpose

Electronic Sax Elesa

Introducing the electronic saxophone, Elesa, featuring an impressively smooth body line. It shares the same keys as a traditional saxophone for easy practice and is equipped with 20 different tones, including saxophone, tenor saxophone, and trumpet. You can play Elesa with six different fingering types, including saxophone, recorder, and trumpet. It comes with built-in reverb and speakers, as well as a headphone jack, making it ideal for night practice. Elesa is a full-fledged electronic saxophone equipped with Bluetooth wireless MIDI, allowing you to control external sound sources. With its Bluetooth Audio function, you can play along with music from your smartphone. Why not try your hand at that longed-for melody?











Tone List

- Soft Alto Sax
 Tenor Sax
 Alto Sax
 Soprano Sax
 Clarinet
- 5 Bari Sax 15 Flute
- 6 Trumpet7 Trumpet Cup16 Piccolo7 Panflute
- 8 Trombone 18 Bottle
- 9 French Horn 19 Harmonica
- **10** Tuba **20** Accordion

Specifications

- Model Name: Elesa10
- Buttons/Keys: 24 buttons/keys
- Tones: 20 tones
- Display: Dot matrix LCD display 128 x 64
- Switch: Power switch, USB/battery selector switch, BITE sensor on/off switch
- Control knobs: VOLUMETRANS/KNOB.1, TONES/KNOB.2
- Jack: USB port (TYPE-C), line out/headphone out
- \bullet Speaker: 45mm × 25mm 5W (RMS) 4 Ω
- Power: 4 AA batteries or USB bus power,
- Continuous use time: Approximately 3.5 hours when using alkaline batteries
- Dimensions: 430 (length) mm x 80 (diameter) mm
- Weight: 406g

Accessories

- USB cable (Type-C to Type A)
- Carry Bag
- Mouthpiece cap
- Strap
- Instruction manual



